TERRANO XT INSTALLATION — TERRANO XT UNIT TO THE LEFT SIDE OF THE HELMET

With the alcohol pad, clean the left side of the helmet in the location of where adhesive plate will be placed



On the adhesive plate, remove the sticker back from the adhesive tape and carefully put the plate in position, then press the adhesive plate firmly to secure the plate on the helmet



Slide the cradle onto the plate until it CLICKS



CLICK the Terrano XT into the cradle



CONTENTS

1. Terrano XT device



2. Cradle



3. Alcohol Pad





For instructional videos please visit: youtube.com/c/TerranoSystems



CYCLING COMMUNICATION TECHNOLOGIES

TERRANO CONNECT APP

- · For easy configuration
- Remote control operation
- On-the-go setting customization





TERRANO XT INSTALLATION — INSTALL THE HEADSET INTO THE HELMET

- Remove any existing stickers in the inside back of helmet
- Use the Alcohol Pad to clean the area
- Use the Large or Med-size Velcro adhesive strip, whichever fits your helmet. Remove the sticker back and stick the velcro strip to the **inside** back of the helmet (see Image 1). Make sure the strip is in a location that will allow speaker position by ear
- Repeat for second speaker on the other side of helmet.
- Adjust so the speaker positions are located at the center of your ears
- Use the small Velcro adhesive strips to hold the speakers wires in place inside the helmet. We recommend at least 12 hours prior to use for the sticker adhesive to reach maximum adhesion





2. Velcro adhesive strips (Ige, med & sml)





3. Alcohol Pad



Adhesive sticky tape strips (soft looped side)



IMAGE 2 -**FRONT** (Inner helmet view)





FINAL HEADSET **POSITION**

